

# Proxicast LAN-Cell Gateway - How to configure a UNAVCO LAN-Cell 2 modem (internal)

423 Beth Bartel June 29, 2009 [Proxicast](#) 756

## How to configure a UNAVCO LAN-Cell 2 modem

### Configuration files

- [UNAVCO\\_aqp3\\_ac881patch\\_cingular](#)
- [UNAVCO\\_aqp3-102708\\_sprint-verizon](#)

### How to configure

1. Reset to Factory Defaults. Login at <http://192.168.1.1>, password "1234". Change password to UNAVCO default, accept new certificate.
2. Update firmware as necessary.
- 3a. Reload firmware/carrier-appropriate UNAVCO config, or reconfigure from scratch--web interface first:







3b. Reconfigure from scratch; add soft reboot timers via SSH interface:

Online URL:

<https://kb.unavco.org/article/proxicast-lan-cell-gateway-how-to-configure-a-unavco-lan-cell-2-modem-internal-423.html>

