Telebit WorldBlazer (T3SA) - Configuration Examples

340 Beth Bartel July 1, 2009 Telebit Worldblazer (T3SA) 11925

Telebit WorldBlazer (T3SA) - Configuration Examples

Suggested modem settings for local connection (modem attached to download computer), firmware v.LA7.05C, receiving data from a Trimble 4000 SSE/SSi

```
WorldBlazer - SA - Version LA7.05C- Active Configuration
 B1   E0   L2   M1   P    Q0   V1   X1   Y0
&C0 &D0 &G0 &J0 &L0 &Q0 &R3 &S0 &T4 &X0
S000:1   S001=0   S002=43  S003=13  S004=10  S005=8   S006=2   S007:120
S008=2   S009=6   S010:70  S011:120 S012:100 S018=0   S025=5   S026=1
S038=0   S041:1   S045:255 S046=0   S047=4   S048=0   S050:6   S051:4
S056=17  S057=19  S058:0   S059=0   S060=0   S061=1   S062=15  S063=0
S064:1   S068=255 S069=0   S090=0   S092=0   S093=8   S094=1   S100=0
S104=0   S105:0   S111:20  S112=1   S113=126 S114=0   S115=0   S116=0
S119=0   S151:3   S155=0   S180=2   S181=1   S183=25  S190:0   S191:6
S253=10  S254=1   S255=0
OK
```

Suggested modem settings for remote connection (modem communicating with GNSS receiver), firmware v.LA7.05C, transmitting data from a Trimble 4000 SSE/SSi

```
WorldBlazer - SA - Version LA7.05C- Active Configuration
 B1   E0   L2   M0   P    Q0   V1   X1   Y0
&C0 &D0 &G0 &J0 &L0 &Q0 &R3 &S0 &T4 &X0
S000:1   S001=0   S002=43  S003=13  S004=10  S005=8   S006=2   S007:120
S008=2   S009=6   S010:70  S011:120 S012:100 S018=0   S025=5   S026=1
S038=0   S041:1   S045:255 S046=0   S047=4   S048=0   S050:6   S051:6
S056=17  S057=19  S058:0   S059=0   S060=0   S061=1   S062=15  S063=0
S064:1   S068=255 S069=0   S090=0   S092=0   S093=8   S094=1   S100=0
S104=0   S105:0   S111=255 S112=1   S113=126 S114=0   S115=0   S116=0
S119=0   S151:3   S155=0   S180=2   S181=1   S183=25  S190:0   S191:6
S253=10  S254=1   S255=0
OK
```

Online URL: https://kb.unavco.org/article/telebit-worldblazer-t3sa-configuration-examples-340.html