Recommended settings for a local FreeWave radio

452 Beth Bartel July 9, 2009 FreeWave 2327

Recommended settings for a local FreeWave radio

```
                              MAIN MENU
                          Version 3.02 07-15-95
                        Modem Serial Number xxx-xxxx

(0)   Set Operation Mode
(1)   Set Baud Rate
(2)   Edit Call Book
(3)   Edit Radio Transmission Characteristics
(4)   Show Radio Statistics
(5)   Edit MultiPoint Parameters
(Esc) Exit Setup


                              SET MODEM MODE
                        Modem Mode is   6

(0)   Point to Point Master
(1)   Point to Point Slave
(2)   Point to MultiPoint Master
(3)   Point to MultiPoint Slave
(4)   Point to Point Slave/Repeater
(5)   Point to Point Repeater
(6)   Point to Point Slave/Master Switchable
(7)   Point to MultiPoint Repeater
(Esc) Exit to Main Menu


                              SET BAUD RATE
                        Modem Baud is  019200

(1)   115,200
(2)   76,800
(3)   57,600
(4)   38,400
(5)   19,200
(6)   9,600
(7)   4,800
(8)   2,400
(9)   1,200
(Esc) Exit to Main Menu
```

```
                                MODEM CALL BOOK
                                Entry to Call is (ALL)
Entry    Number     Repeater1    Repeater2
(0)     slave 1
(1)     slave 2
(2)     000-0000
(3)     000-0000
(4)     000-0000
(5)     000-0000
(6)     000-0000
(7)     000-0000
(8)     000-0000
(9)     000-0000
(C)     Change Entry to Use (0-9) or A(ALL)
(Esc)   Exit to Main Menu
Enter all zeros (000-0000) as your last number in list


                              RADIO PARAMETERS

WARNING: Do not change parameters without reading manual

(0)   FreqKey          5
(1)   Max Packet Size  8
(2)   Min Packet Size  2
(3)   Xmit Rate        1
(4)   RF Data Rate     3
(5)   RF Xmit Power    9
(Esc) Exit to Main Menu
```

Online URL: https://kb.unavco.org/article/recommended-settings-for-a-local-freewave-radio-452.html