

How to configure a Mac for a Keyspan USB-to-serial cable

505 Beth Bartel March 24, 2010 [General Resources](#) 2062

How to configure a Mac for a Keyspan USB-to-serial cable

1. Install the latest driver from Keyspan:

http://www.keysSpan.com/downloads/homepage_pn_usa19hs.spml

2. Open up a terminal window. Type:

```
ls -lt /dev/tty* | head
```

This will list your ports:

The keyspan serial port is /dev/tty.USA19H3d1P1.1

3. Use the unix "cu or minicom" command to communicate with the NetRS (like hyperterminal):

```
cu -l /dev/tty.USA19H3d1P1.1 -s115200
```

or

```
minicom -s (then setup minicom to your serial port)
```

If you do not have minicom you can get it here:

<http://mac.softpedia.com/progDownload/Minicom-Download-25366.html>

Online URL:

<https://kb.unavco.org/article/how-to-configure-a-mac-for-a-keysSpan-usb-to-serial-cable-505.html>