Proxicast LANCell Gateway - How to configure the VPN on a LAN-Cell 2 modem (internal)

425 Beth Bartel February 9, 2018 Proxicast 447

How to Configure the VPN on a LAN-Cell 2 modem (internal)

From SSH configuration interface, check to see if local access to VPN'd modem is enabled:

From VPN Config Menu:

1. Add Gateway Policy

2. Add Network Policy

From Network>LAN Config Menu:
Trom retworks Exart Corning World.
After applying LAN changes, you will lose connection to the modem and then it should assign you a new IP.
Online URL:
https://kb.unavco.org/article/proxicast-lancell-gateway-how-to-configure-the-vpn-on-a-lan-cell-2-modem-internal-425.html