How to install Nut v0.45.4-1 on Linux with the APC BackUPS Pro 280VA (September 2002)

297 Beth Bartel November 19, 2008 RedHat Linux 1210

How To Configure Nut v0.45.4-1 on Linux with the APC BackUPS Pro 280VA

(v1.0, 27Sept2002 written by: Jay Sklar)

This How-To explains the steps involved in setting up a Dell or Penguin computer system with Red Hat Linux v7.3 for use with the APC BackUPS Pro 280VA uninterruptible power supply (UPS) and Network UPS Tools (NUT) software. The document is divided into 7 sections:

1.	
	Requirements
2.	
	Hardware Configuration
3.	
	Software, Part 1 (installation and configuration)
4.	
	OS Configuration
5.	
	Software, Part 2 (configuration)
6.	
	Testing
7.	
	Troubleshooting

[See <u>attached .pdf file</u> or <u>attached .doc file</u> for more.]

Online URL:

https://kb.unavco.org/article/how-to-install-nut-v0-45-4-1-on-linux-with-the-apc-backups-pro-280 vaseptember-2002-297.html