


Dial-up Landline (Analog) Modems - Communication Configuration Diagrams [historical]

339 Beth Bartel September 16, 2009 [Comms and Networking Examples \(Diagrams\)](#), [Dial-up Landline \(Analog\) Modems](#) 17693

Dial-up Landline (Analog) Modems - Communication Configuration Diagrams


Download rates will vary depending upon site location, local interference, phone line quality, and cellular service.

Receiver--Radio Modem--Radio Modem--Phone Modem--Phone Modem




NOTE: The use of a repeater and directional antennas depends on the specifics of the site, distances signals need to travel, topography etc.


Receiver--Phone Modem--Phone Modem--Internet Service Provider



Trimble Receiver--Phone Modem--Phone Modem--PC



TurboRogue Receiver--Phone Modem--Phone Modem--PC



Online URL:

<https://kb.unavco.org/article/dial-up-landline-analog-modems-communication-configuration-diagrams-historical-339.html>