

Suggested configuration for a FreeWave DGR-115H radio modem connected to a Trimble 4000SSE/SSi GPS receiver

431 Beth Bartel June 19, 2020 [FreeWave](#) 660

NOTE: The outdated and offensive "master-slave" terminology has been replaced with "Access point (AP) - Station/Endpoint (STA)" in all instances, but will still remain in the configuration software when implemented.

Below are the suggested settings of the FreeWave Wireless Data Transceiver when directly attached to a Trimble 4000 SSE/SSI receiver and using the Trimble "rfile" program. The modem is set at 38400 baud.

Base Modem:

Operation mode: Point to Point Master

Baud Rate: 38400

Call book: Set to call the serial number of the remote modem.

Transmission characteristics:

FreqKey = 0-9

Max Packet Size = 8

Min Packet Size = 2

Xmit Rate = 1

RF Data Rate = 3

RF Xmit Power = 9

Remote Modem:

Operation modem: Point to Point Slave

Baud Rate: 38400

Call book: Put serial number of base modem into call book.

Transmission characteristics:

FreqKey = 0-9

Max Packet Size = 8

Min Packet Size = 2

Xmit Rate = 1

RF Data Rate = 3

RF Xmit Power = 9

Remote Receiver:

BAUD RATE/FORMAT CONTROL MENU set to 38400, 8, N, 1, no flow control.

REMOTE PROTOCOL MENU set to DATA COLLECTOR COMPATIBLE.

Attach the receiver to the remote modem via a null modem cable.

Online URL:

<https://kb.unavco.org/article/suggested-configuration-for-a-freewave-dgr-115h-radio-modem-connected-to-a-trimble-4000sse-ssi-gps-receiver-431.html>