

# SuomiNet - FreeWave Wireless Communication Link

594 Beth Bartel June 18, 2020 [SuomiNet](#) 794

**NOTE: The outdated and offensive "master-slave" terminology has been replaced with "Access point (AP) - Station/endpoint (STA)" in all instances, but will still remain in the configuration software when implemented**

*Note - content is provided for historical continuity and may be out of date. The UNAVCO SuomiNet pages are not actively maintained, and up-to-date SuomiNet information should be obtained from UCAR's COSMIC program at: [www.cosmic.ucar.edu/suominet.html](http://www.cosmic.ucar.edu/suominet.html)*

**Part List** - The following parts are required for Configuration 3 SuomiNet sites using a radio link between the GPS receiver and the system computer.

## Configuration 3 radio link part list

Qty	Item	Part Number	Unit Price
2	<a href="#">FreeWave 900 MHz radio modem</a>	DGR-115R	~\$1,170
Includes:	110VAC power supply		
Includes:	DB9 serial cable		
2	<a href="#">Yagi directional antenna</a>	EAN0906YB	\$67.50
2	N male - N male antenna cable	various	contact <a href="#">FreeWave</a>
1	DB9 null modem adapter		
1	DB9 male-male adapter		

### FreeWave parts available from:

FreeWave Technologies, Inc.  
1880 South Flatiron Court  
Boulder, CO 80301  
(303) 444-3862  
(303) 786-9948 fax  
[www.freewave.com](http://www.freewave.com)

To configure the radio modem:

1. Login as user *suomiops*
2. Connect the modem to the computer serial port 2 using a straight serial cable
3. Type the following command: `cu -l /dev/ttyS1 -s19200`
4. Press the setup button on the radio modem to see the configuration menu

## DGR-115R SuomiNet Configuration Settings

### Operation Mode:

- (0) Point to Point Master (computer end radio)
- or
- (1) Point to Point Slave (GPS receiver end radio)

### Baud Rate:

- (4) 38,400

### Call Book:

Number corresponding to the other radio modem.

### Radio Transmission Characteristics:

- (0) FreqKey 0
- (1) Max Packet Size 9
- (2) Min Packet Size 0
- (3) Xmit Rate 1
- (4) RF Data Rate 3
- (5) RF XMIT Power 9
- (6) Slave Security 1
- (7) RTS to CTS 0
- (8) Retry Time Out 255
- (9) Lowpower Mode 0

### MultiPoint Parameters:

- (0) Number Repeaters 0
- (1) Master Packet Repeat 3
- (2) Max Slave Retry 9
- (3) Retry Odds 9
- (4) DTR Connect 0
- (5) Repeater Frequency 0
- (6) NetWork ID 255
- (7) Reserved
- (8) MultiMasterSynch 0
- (9) 1 PPS Enable/Delay 255
- (A) Slave/Repeater 0
- (B) Diagnostics 0
- (C) SubNet ID Disabled
- (D) Radio ID Not Set

### TDMA Menu: NA

Online URL: <https://kb.unavco.org/article/suominet-freewave-wireless-communication-link-594.html>

